


# User Manual for Dinosaur Design Kids Digital Alarm Clock



## Specifications

- Material: ABS + PC + rubber
- Size: 9 x 12 x 12cm



- |                      |              |                   |
|----------------------|--------------|-------------------|
| 1. Alarm clock 1 / 2 | 6. AM        | 11. Alarm         |
| 2. Snooze            | 7. PM        | 12. Button -      |
| 3. Sleeping training | 8. Time      | 13. Charging port |
| 4. Battery indicator | 9. Settings  | 14. Light         |
| 5. Temperature       | 10. Button + | 15. Reset         |

## Time settings

To set the time, long-press the settings button for 2 seconds. The first thing you'll set is the date by pressing the + and - buttons. Press the settings button to confirm, then choose between 12 and 24 hours format, confirm via the settings button, and then set the time.

Press the settings button to select the notification tone and use the + and - buttons to choose. For voice-time broadcasting select B00 to turn it off, B01 to allow the clock to tell time all day, and select B02 to allow it to tell time only during the day (from 6 AM to 8 PM).

## **Alarm clock settings**

Press the Alarm button to check the alarm. To enter the alarm settings, long-press the alarm button for 3 seconds. Set the Alarm 1 using the + and - buttons, then select the days that you want the alarm to go off, and finally select the ringtone. When done, repeat the steps for Alarm 2.

When the alarm goes off, press the settings button to snooze it. The snooze icon will appear on the display. Snooze time is 5 minutes and you can snooze it maximally 3 times.

## **Countdown**

The countdown can be set for 1 to 59 minutes. To set it, long-press the - button for 2 seconds, and it will go into the countdown settings after the beep. You'll see a default value of 00:30 on the display which can be adjusted using + and - buttons. The countdown will start 3 seconds after setting the time. It will beep for 3 minutes after the countdown is finished.

## **Night light settings**

Press the Settings button to turn on the LED night light and the "LE45" will start flashing on the display. Press the + or - buttons to set the time the light goes off. The default time is 45 minutes, and you can set the range between 1 and 60 minutes.

If the alarm is set overnight, the night light will turn on 10 minutes before the alarm goes off. When the alarm ends, the night light will also turn off. You can also turn off the night light by pressing the settings button.