


# **User Manual for Cute Zoo Dual-Lens Kids Digital Camera with 32GB Memory Card**



## Specifications:

- Screen: 2" IPS
- Camera: 20MP
- Video resolution: 720p
- Battery capacity: 600mAh
- Storage: microSD card up to 32GB
- Dimensions: 80 x 60 x 45 mm
- Weight: 90g



1. Shutter/Confirm button
2. Power/Switching button
3. Set/Delete/Return button
4. Switch buttons
5. Album button

## Operation instructions:

- Long press the power button to turn it on/off
- Short press the power button to switch front and rear camera
- Short press the shutter button to take photos
- Press and hold 2 seconds the shutter button for video recording
- If the camera start behaving abnormal, use a paper clip and insert it in the reset hole to reset the camera